

济南儒祺商贸有限公司

JINAN RUQI TRADING CO., LTD

乐陵市博宇建筑五金有限公司

LAOLING BOYU BUILDING HARDWARE CO., LTD

单品技术文件Single technology file

Contact: VICTOR LIU
Tel:+86 186 6016 9418
(WeChat&WhatsApp)
Website:www.boyuwj.com


整套门锁 (Full set lock)



把手 handle



锁体 lock body



锁芯 cylinder

● ● ● 整套门锁 (Full set lock) ● ● ●

1. 门把手 (Handle) :

中心距 (把手中心至钥匙孔中心的距离) 为85/92。

Center distance (The distance from hand center to key center is 85/92.)

需确认(Need to be confirmed):

1. 中心距离 (85/92)

(Center distance)

2. 把手的颜色, 款式

(Hand's color and type)



● ● ● 整套门锁 (Full set lock) ● ● ●

2. 锁体 (Lock body) :

中心孔距的距离为85/92。

Center bore distance is 85/92.

中心孔到边的距离为30/35/40/45

The distance from center bore to side is 85/92.

需确认(need to be comformed):

1.中心孔距 (85/92)


Center bore distance

2.中心孔到边的距离 (A)

The distance from center bore to side (A)

3.如果是多点门锁要确认门的高度以便确认所需连杆的尺寸.

if it is Mut.door lock ,need to check the size of the door .



● ● ● 整套门锁 (Full set lock) ● ● ●

• 3. 锁芯 Cylinder:

从外形分为偏芯和正芯，带旋钮还是不带旋钮。

From outline we can divide into in the core or core shift, have the knob or not .

锁芯的长度由型材的厚度决定。

Cylinder's length is depend on profile's thickness

需确认:

1. 锁芯长度, Cylinder's length

2. 正芯还是偏芯, (偏芯有偏芯值)

In the core or core shift (core shift have core shift number)


3. 单开 (一边旋钮一边钥匙) 还是双开 (两面都是钥匙)

Single open (one side is knob other side is key) or double open (two sides are key)

4. 旋钮形状 The shape of knob

5. 表面颜色。Color of the cylinder


1.



2.



3.



● ● ● 安装流程图 (Installation flow chart) ● ● ●



选择型材
(Chose profile)



安装锁体
(Install lock body)



安装右边把手
(Install right handle)



安装左边把手
(Install left handle)



安装锁芯
(Instal cylinder)



整体安装好的效果
(Full set lock)



谢谢观看

THANK YOU